

# QUICK SETUP GUIDE

---




*go*  
**COLOP**<sup>®</sup>  
e-mark

# 1. e-mark<sup>®</sup> go assembly



1

Remove from docking station



2

Open front door



3

Remove film from print head



4

Insert cartridge

**Be careful,**  
do not touch  
any contacts or  
the print head!



5

Close front door and charge for 2 hours



6

Switch on



7

Print your SSID & Password!



8

Put the e-mark go always back into the docking station after printing!

## 2. Download and setup your app

Download on AppStore  
or Google Play Store:




### Benefits for registration:

- access to template/clipart store
- new templates & cliparts in the
- store regularly updated
- synchronisation between different devices




## 3. Connect your e-mark® go

Click on "Scan QR code"  
and scan the **QR code** ...



OR



... manually enter the **SSID and password**,  
which is found on (see below)



imprint after reset  
or first imprint



Device name:  
COLOP e-mark go  
Manufactured for  
COLOP Digital GmbH  
Made in Austria  
SSID: emarkgo10dass  
PWC: ea40007d

packaging




label on the  
e-mark go

## The e-mark<sup>®</sup> go at a glance

---

- 1** Front door
- 2** Print head of cartridge
- 3** Sliding wheels
- 4** Magnets
- 5** Reset hole
- 6** Optical sensor
- 7** USB-C port - for charging only
- 8** Exchangeable handle label
- 9** Docking station with protective cap for the print head




# Light indicators



## Blue position LEDs

Use the blue lights to position your imprint. The light shows the top and bottom of your imprint.



## Battery indicator

**green** 41 - 100 %, **yellow** 11 - 40 %, **red** 0 - 10 %



## Printing indicator

**green:** ready to print; all lights **blinking red:** cartridge empty, no cartridge, device error



## Wifi connection indicator

**blue:** active Wifi connection  
**no light:** no connection



	Behaviour	Description
	Beep once	Print job transmitted
	Beep twice	Print is complete, Cleaning cycle finished
	Beep continuously	Print head warning: put it back on the docking station
	Beep continuously	Error - switch it off/on

# Print head cleaning

---

The cartridge is a sensitive part and requires special care. Especially when the e-mark® go is not used on a daily basis, more intensive cleaning is necessary. We recommend weekly cleaning.

## **Automatic cleaning cycle**

Whenever the e-mark go is taken from the docking station, the print head is cleaned automatically. The intensity of cleaning increases the longer the e-mark go is not used.

1. Take e-mark go from docking station
2. Hold briefly in the air (wait for ink to disperse)
3. Put on paper & print!

Before printing on a ribbon, special paper or material, we recommend doing a test imprint.

## **Manual print head cleaning**

1. Take a slightly dampened piece of cloth (only pure water, no cleaning agent!)
2. Take the e-mark go out of the docking station
3. Wipe the print head from top to bottom (never sideways, as this could damage the cartridge)

For a more intense clean try the quick cleaning in the app.



# Need some help?

---

Setup Video



[emarkgo.colop.com/  
setup](http://emarkgo.colop.com/setup)

Full  
User Manual



[emarkgo.colop.com/  
usermanual](http://emarkgo.colop.com/usermanual)

Help Centre/  
Support



[emarkgo.colop.com/  
helpcenter](http://emarkgo.colop.com/helpcenter)

Still not satisfied?  
Contact us, we are happy to help you:  
[emarkgo.colop.com/support](http://emarkgo.colop.com/support)

## Happy?

That's great! We would really appreciate your positive review or comment on Facebook, Instagram, Amazon or our online shop. Thank you.